

# DANCOVER™

Big or Small we cover it all...

## Assembly manual Party Tent 6 x 12 m PVC

### Introduction:

Please Read this Manual before use.


Check the contents of all the boxes are similar with the packing list.

Select a flat ground to erect the tent.

<b>UK</b> Tel.: 020 7221 0220 mail@dancover.co.uk	<b>Germany</b> Tel. 041 0266 7040 mail@dancover.de	<b>France</b> Tel. 0810 000 219 france@dancover.com	<b>Spain</b> Tel. 902 947 551 espana@dancover.com	<b>Italy</b> Tel. 02 303 75317 italia@dancover.com
<b>Switzerland</b> Tel. 084 0000 125 schweiz@dancover.com	<b>Austria</b> Tel. 0662 626 935 austria@dancover.com	<b>Denmark</b> Tel. 70 26 76 20 mail@dancover.dk	<b>Norway</b> Tel. 231 00 690 mail@dancover.dk	<b>Sweden</b> Tel. 040 233 262 mail@dancover.se




I Lay all poles and connectors out one the ground as shown in the diagram. Insert poles no.1 and pole no.2 into fittings. (6,7,8,9,10,11)




III

Lift up one side of the roof structure and insert legs no.3. Pull the roof cover over the roof-structure and fasten it with bungees-balls. (do not fasten all bungees in one side as the cover maybe to tight in the other side). Lift up the other side and fit with bungees. WARNING: Do not pull in the leg fabric welded to the roof.




II

Attach support poles no.4 with connector 10,11. Attach part no.5 to no. 8,9 and fasten to support-bar (no.4)




IV

Lay out all pipes (no.2) and connectors 12,13,14 on the ground as the picture shows. Connect them and tighten the screws afterwards.




V

Attach side walls and end/door walls to structure by using bungees. Let the bungees grasp side and end wall around the same frame pole to ensure stability. Use the short stake pegs to ensure the panels to the ground.



VI

The Guy lines clasp to each corner of the tent and another end of line fix to ground by pegs.



**Warning**

1. In order to avoid being rusted, oil is covered on the surface of the pipes. Before set up! Please remove the oil carefully to keep the cover clean.
2. Take note that the tent needs to be handled carefully to avoid damage.
3. Do not force the frame as they may be damage in the process.
4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.  
Please select a suitable site for the tent to avoid the damage to underground sprinkler systems, water, gas or electrical lines.
5. Open flames and heaters with open flames such as heating mushrooms should not be used at all.